

Chassis	Part Symbol	Defective Circuit	Symptom	solution
TVD809	Mech_DVD	Mechanical	No audio and the dvd is inoperative, the door won't even open. The unit appears to be in the dvd lock mode. The DVD unit was found to be at fault. Replacing the dvd unit restored normal operation. (This was the latest version of the dvd.)	Replace DVD